




Position	Spare parts	Part number
1	Inverter board	033091390400
2	PC board (Heat)	033090310400H88
3	Oval LED (Heat)	034090260000
4	Power filter plate	033092330000
5	Reactor	041301080000
6	Electronic expansion valve	006121000001
7	4-way valve	006110080001
8	Water flow switch	040060620000
9	Fan motor	032020550000
10	Fan motor capacitor	041010030001
11	Full set of sensors	Z35043000400
12	Compressor	031084030000
13	Titanium heat exchanger(Heat)	001031180002
14	Evaporator	Z01011490000
15	High pressure protection switch	040050630000
16	Low pressure protection switch	040050130000
17	Low Pressure valve	006080500000
18	Water union (black,50mm)	003990020000
19	Water union gasket	004980050002
20	Fan	007010140000
21	Drainage kit	Z03991700000
22	Compressor insulation cap	004041660000
23	Top cover	002021300615
24	Front Panel	002021300315
25	Right Up Panel	002020621715
26	Right Down Panel	002020621815
27	Back Panel	002021321215
28	Bottom board	Z02021321000
29	Pole	002020800215